




Large Premium Plus A-Frame Doghouse

Assembly Instructions


Item #01707

#30001707


Feet x4
#900102




Back Panel
#900930




Front Panel
#900931




Left Side Panel
#900932



Right Side Panel
#900933




Floor Panel x2
#900934




Roof Panel x2
#900935


Roof Ridge Cap
#900354



8 - Nuts & Bolts



8 - 1 1/4" Screws



4 - 1" Screws




3 - Stars

Hardware: #900929

Step 1


Connect the Front Panel and the Back Panel to the Left Side Panel and right Side Panel using the 8 - 2 3/8" Nuts and Bolts (A).



Step 2


Insert the two piece floor panel into the assembled doghouse

Tip: The corners of the floor panels are notched to fit the outside corners




Step 3

Attach the two piece Shingle Roof Panels to the assembled doghouse using the 8 - 1 1/4" screws (B).



Step 4

Place the Ridge Cap onto the Shingle Roof Panels and secure using 4 - 1" screws (C). Attach 3 star shaped bolts (D) on the doghouse door frame in the threaded holes.



Ware Tip

Your Premium⁺ Doghouse has four adjustable feet, designed to allow you to level your doghouse

Care Tip

To protect the wood on your doghouse you need to re-apply the protective stain finish at least 1x each year. Use a safe and non-toxic water based stain (available at your local paint or hardware center). Keep doghouse in a safe area away from high winds and extreme temperatures.

If you have any questions or concerns about this product, contact our customer service department at 1-800-295-2243 or cs@waremfginc.com and we will help you with any problems, Mon-Fri 8:00 – 4:00 MST